


General Instructions (64-65 Lincoln Continental)

The following general instructions are to be used only as a guide.



Quality Restoration Rubber Parts

Removal tips





Cut inner lip off of weatherstrip above the pinchweld. Slide a flat teflon knife or spatula between the rubber and glass and the body to release the rubber from the glass and the body. Carefully push glass from the inside upper corners and center, applying even pressure. Do not over push. If you do not feel it starting to give, then check the weatherstrip, both inner and outer, to make sure that it had released from the body and that it is clear of the pinchweld. It should remove easily.

Clean up body area of all putty and dirt. Make any repairs. If reusing the same glass, clean thoroughly around perimeter of glass.

Installation:

Fit rubber to windshield frame.

Trim to fit outer lip of lower weatherstrip as needed (Approximately 11 1/4" at each end).



Lubricate the 1/4" glass groove to allow the glass to find center while installing. Place new rubber on glass making sure that it is placed correctly and fits well. Any problems with fit will show up at this point. Rubber should fit glass without being too loose or too tight. Improper size will pucker or fold in corners. Place chrome strips clip in slots of rubber first. Place 3/16" cord in pinchweld slot of rubber around perimeter to help pull flap over pinchweld.

Place a bead of sealant from the bottom outer corner of the pinchweld, all around the opening. Lubricate base area of weatherstrip with soapy water. Position the glass with the weatherstrip on center and place the bottom so that it starts to lip over the pinchweld. Pull the cord slowly making sure that the lip is lapping over the pinchweld. At this point, it would be helpful to have a helper pushing down on the glass, to help it seat against the body. Pay particular attention to the bottom outside lip of the rubber so that it doesn't fold under. If it looks as though it might, then place a section of cord along the bottom underneath the lip. Once the inner cord is pulled along the bottom, then the outer cord can be pulled to properly position the outside lip.

Note: Cord should always start at lower center and be pulled evenly in both directions. Do not let glass get cocked in one direction, it will put pressure on curve of glass and cause breakage.

Once the bottom is in place, work up the sides, then top, while applying down pressure on the glass. When the top lip is pulled in over the pinchweld, the glass should drop in place. Check inner and outer perimeter to make sure that it is laying flat. Once the rubber and glass is in place, put clear sealer between rubber and glass on outer side with flat blade applicator. Clean excess sealant.