

20-0525-72

1956 Ford Pickup Door Seal



STEP 1- Remove old seal & clean off the old glue material from door.

STEP 2- Place the new door seal in position so that the special molded sections are in the correct places.

STEP 3- Glue the molded sections first, then work down the rest of the door gluing the extrusion in place.

